

Bronco Raptor Installation Notes

Follow the installation procedures for the standard Bronco hard top with these exceptions.

- The B-Bracket needs to be removed using the Raptor tool kit.

Take the three **larger bolts** off on both sides. Don't lose them! Lay it aside so it can be reinstalled after the shade is on.

- **Install the shade following the installation video for the standard hard top Bronco.**

- When pulling the shade to the rear make sure the straps are between the the rear brace. There are also two bolts and the webbing should be pulled over them so it lays flat. If it's not pulled far enough the webbing will stick up it.

- After the shade has been fully installed put the B-Bracket back on and make sure everything is good and tight!

